

Jacobson Reelmower Checklist

Do not use the reel mower when grass is wet.

Ensure green is clear of debris.

Place ramp at North shed and wheel out the Jacobson

Check fuel is in tank, do not refill on the green

Turn on RED switch

Choke and fuel tap are under the air filter body, open fuel tap and set choke on

Pull starter cord with sharp tug

When motor starts allow to warm up before turning choke off

Ensure speed paddle is to minimum

Carefully engage traction by pushing BLACK WIRE LOOP to left and close to handle

Jacobson will jerk forward, be careful

Drive to green's access ramp, lift mower onto stand

Remove traction wheels

Lower the stand and engage traction to position the mower on the green, tilting it back on the cylinder to protect cutters

Commence cutting by engaging clutch lever (on front edge of cutters), if it will not engage rock cylinder slightly until you can engage

Be careful not to catch cutters on wooden edge of green

Empty cuttings box frequently, before clippings spill onto green

After covering the green, cut a double boarder around the green

Using traction only manoeuvre the mower off the green

Refit traction wheels

Take to hosepipe and clean cutters and cylinder