

Toro Reelmower Checklist

Do not use the reel mower when grass is wet.

Ensure green is clear of debris.

Place ramp at North shed and wheel out the Toro

Check fuel is in tank, do not refill on the green

Turn on switch with ORANGE strip

Fuel tap is not turned off on the Toro

Set choke to ON (lever visible in front of body)

Pull starter cord with sharp tug

When motor starts allow to warm up before turning choke off

Carefully engage traction only by pushing BLACK right hand lever straight forward

Toro will jerk forward, be careful

Drive to green's access ramp, lift mower onto stand

Remove traction wheels

Lower the stand and engage traction only to position the mower on the green, tilting it back on the cylinder to protect cutters

Commence cutting by pushing traction lever inwards and forward

Be careful not to catch cutters on wooden edge of green

Empty cuttings box frequently, before clippings spill onto green

After covering the green, cut a double boarder around the green

Using traction only manoeuvre the mower off the green

Refit traction wheels

Take to hosepipe and clean cutters and cylinder